Culligan quench

1010 Pre-Installation Checklist

Thank you for being a Culligan Quench customer! We are excited for your workplace to experience the great-tasing crescent ice from your new 1010. Before our certified technician can install your machine, the following preinstallation requirements must be completed.

WaterSupply

- Potable cold water supply ONLY
- 3/8" OD 1/4" ID copper pipe or equivalent terminating in a standard plumbing fitting that Culligan Quench can connect to (connection point must be accessible for service and installation)
- Minimum water pressure 14.5 PSI, 0.9 gallon per minute minimum flowrate
- Maximum water pressure 51 PSI
 - Must be a dedicated 3/8" ID water supply line with no other connections
 - o Any water line or valve less than 3/8" ID is not acceptable

Electrical

- Ice maker: Dedicated 115 VAC/60Hz/20 amp electrical circuit
 - o Culligan Quench technician will install a 12/3 power cord with a 5-20 plug
- Ice storage bin: Dedicated 115VAC/60Hz/15 amp electrical circuit
- Electrical circuits must be within 5' of machine location; NO EXTENSION CORDS

Placement

- Unit must be placed on firm and level foundation and away from other equipment that produce heat
- Recommended air temperature range at the site 45°F 100°F;
- Recommended water temperature range at the site 45° F 90°F

Drain

- Floor drain required. Must be within 10 feet of the installation site.
 - o Culligan Quench technician will plumb the ice maker and ice storage bin to the site drain using 1-inch PVC pipe
- Remote drains using condensate pumps cannot be used.

Ventilation

• Ice maker requires 12" of open space around all sides and top

If you have any questions about the installation, call Customer Care at 888-554-2782



Talk to your dedicated Culligan Quench Water Expert. Phone 844-557-8320 Website www.culliganquench.com